



UR062500 Urine Bags

INSTRUCTION FOR USE

DESCRIPTION

m|devices hospital Urine Bag is provided sterile and consists of a non-return valve, needleless sample port, T-Tap, integrated reinforced hanger, 120cm length of tubing and a 2500mL volume capacity.

The T-Tap end allows for ease of use to empty the Urine Bag and the clear incremental measurements allow for precise visual urine output.

THE BELOW IS ONLY A SUGGESTION AND FACILITY
PROTOCOL MUST BE FOLLOWED FOR ALL CLINICAL
PROCEDURES WHERE THIS PRODUCT IS USED.

CAUTION

- Single use.
- DO NOT re-sterilise.
- DO NOT store at extreme temperatures and humidity, avoid direct sunlight. Handle with care.
- STERILE (EO), DO NOT use if the package or product has been damaged or contaminated.
- EU Notice: any serious incident that has occurred in relation to the device should be reported to the manufacturer and the competent authority of the Member State in which the user and /or patient is established.

STEPS

1. Perform hand hygiene.
2. Remove bag from the packaging and check that the T-Tap at the distal end of the bag is closed.
3. Using aseptic technique, remove cap from the drainage tubing and connect directly into the funnel of the urinary catheter.
4. Ensure the connection is secure.
5. Hang the bag at or below the patient's bladder level.

TO EMPTY THE URINE BAG

1. Perform hand hygiene and don gloves.
2. Place a receptacle directly under the T-Tap of the Urine Bag.
3. Holding the T-Tap in one hand, with fingers on either side of the tap, gently push against the mechanism to slide the tap across the T connection to open the tap to allow the urine to empty.
4. Once the bag is empty, repeat the above step but in the opposite direction to close the tap.

ACCESSING THE NEEDLELESS SAMPLE PORT

- Swab needleless sampling port with an approved antiseptic wipe as per facility protocol. Allow to completely dry.
- Close slide clamp on tubing below sample port.
- Using a sterile luer slip syringe, insert directly into the sampling port and twist to engage and secure connection. Withdraw desired volume of urine for sample.
- Remove syringe from sampling port. Repeat above steps each time the sampling port is accessed.

PRECAUTIONS

- Ensure the Urine Bag is never raised higher than the level of the bladder.
- Ensure the Urine Bag tubing is free from kinks at all times when connected to the catheter.
- At the completion of emptying the bag, check to ensure the T-Tap is completely closed.
- Ensure aseptic technique is maintained when handling, connecting and disconnecting the Urine Bag from the urinary catheter.

m|devices

27 Llewellyn Avenue
Villawood NSW 2163
Australia
T +61(0)2 8718 2800
F +61(0)2 8718 2801



CONTINENCE
CARE Urine Bags



Multigate Co., Ltd.
7 Lanjiang Road 312000
Shaoxing China



RFX+Care International A/S
Bakkegaardsvej 408
3050 Humlebaek
Denmark

STERILE EO



MD



0123